

DL 580 LED

Instrukcja montażu









Installation instructions

Instructions de montage


Montageanleitung

IP20

230 V
50 Hz




- PL – Wyłączyć zasilanie przed wymianą lampy;
- UK – Disconnect the unit before changing the lamp;
- F – Débrancher l'appareil avant de changer la lampe;
- D – Von den Auswechsellin der Lampe die Leuchte von der Netzspannung trennen.




IMPERIAL S.K.A.
ul. Kobylnicka 85, 78-200 Białogard
tel./fax 94 312 78 20, tel./fax +48 94 312 78 69
NIP 672-000-62-93

imperial®


1



2



3



IMPERIAL S.K.A.
ul. Kobylnicka 85, 78-200 Białogard
tel./fax 94 312 78 20, tel./fax +48 94 312 78 69
NIP 672-000-62-93

imperial®